尺寸: 60*170MM, 157g铜版纸单K单面印刷, 折页



Thank you for purchasing NEO A3.


Easily control your MINIX Media Hub for Android with NEO A3 wireless air mouse.

Every aspect is designed to make commanding your entertainment easy, using the latest six-axis gyroscope technology and featuring a dedicated multimedia kevpad.

Enjoy the convenience of voice input when using the built-in microphone, giving you immediate access to information and content.

A full keyboard on the reverse side, in a familiar layout provides hours of typing comfort. Solid build with large, carefully crafted keys means browsing the web, chatting with friends and more, are completed with absolute ease.

- Battery requirements: 2 x AAA batteries (not included)
- Operating range: 10 meters (5-7 meters for infra-red power button)



Key Layout - Back

Long Press - Power On / Power Options Menu* Short Press - Enter Sleep Mode* Settings Menu* Recent Apps List* Launcher Home Screen Directional Pad Left-click (on Enter when using D-Pad) Return / Back Activate Microphone Flv Mode Volume Down Installed Apps List* Volume Up Play / Pause Fast Forward * = Only compatible with MINIX Media Hubs for Android

Operating Status LED Microphone Status LED Caps Lock LED Fn Key LED Re-pairing 1. Remove both batteries, then reinsert. 2. Press Fn + P on the keyboard. 3. Caps LK & Fn LEDs will glow. 4. Plug the receiver into a USB port on your MINIX Media Hub for Android or other compatible electronic device. 5. LEDs will flash three times when successfully paired.

- seconds to turn the microphone off.
- microphone button to record voice.

- Toggle the on/off switch to activate fly mode.
- Turning to the keyboard side will automatically disable fly mode.
- Turning back to the front side, the previous mode will be resumed.

Recalibrating Sensors

- 1. Press Fn + Y on the keyboard.
- 2. Fn LED & operating status LED (1) will glow.
- 3. Leave the remote on a flat surface for a few seconds.
- 4. LEDs will flash four times when successfully calibrated.

Microphone Input Function

- 1. Tap on the microphone icon inside an app if the microphone doesn't activate automatically.
- 2. Microphone status LED will glow when it's in use.
- 3. Press and hold the microphone button for 5
- 4. For voice recording software, press and hold the

- Press Fn to switch between white and orange characters.
- Press Fn + Shift to use the bottom row orange characters.

www.minix.com.hk